



### Step 1: Remove Belt Strap

Slide the belt strap out and away from the buckle.



### Step 2: Cut Belt Strap

- 1 ADD 4 inches to your pant size using the scale on the back side of the belt strap.
- 2 CUT the belt strap with sharp, heavy-duty scissors.




#### Tips

- a If pant size is close to 50" – DO NOT cut belt. Proceed to step 3.
- b First cut should be longer to allow for further corrections.


### Step 4: Close Clamp

- 1 Apply sufficient force to close the clamp.
- 2 Install the screws with the included wrench. **DO NOT Over Tighten.**




### Step 3: Re-Insert Belt Strap

- 1 Slide the belt strap into the buckle.
- 2 Ensure the belt strap is against the back of the clamp housing before closing the clamp.




### Step 6: Release Belt

- 1 With the right hand, push the belt strap towards the buckle.
- 2 Pull the release lever, away from the body, with left hand and hold.
- 3 Pull the belt strap out with the right hand.



### Step 5: Tighten Belt

- 1 Feed the belt strap through the belt loops and insert the strap end through the buckle until a ratcheting sound is heard.
- 2 Pull until the belt feels snug. **DO NOT Over Tighten.**



#### Tip

End of belt strap should extend past the first belt loop by 2-3 inches. If belt is too long – remove the buckle and cut off one inch at a time until the desired length is achieved.